




# Lubricate the Z Rod




# INTRODUCTION

Not the guide you are looking for?

Go back to the [← Easy Kit Build Flow.](#)

## Step 1 — Lubricate the Z Rod




- Rotate the Z rod to move the whole X assembly about *this* high.

## Step 2



- Get some of that *lithium grease* from the little pack in the tools box.

## Step 3



- Apply the grease below the zx coupler.
- As the X assembly will travel up and down during future prints, it will distribute the grease.

## What's Next?

Get back to the [← Easy Kit Build Flow](#) and continue with the next guide.