Install the X Assembly

#jb2.1.b.b-mkr-h



© 2021

Step 1 — ↳ Insert the X Assembly



Step 2







Step 3



Step 4







⚠ Leave the zip ties loose.

Step 5



Step 6



Step 7







Step 8







Step 9



Step 10







⚠ Be gentle. Do no force the rod and keep it straight or*you may damage the ball bearing by knocking some balls out.*

Step 11



Step 12





⚠ BE GENTLE. Do no force the rod and keep it straight or*you may damage the inside of the bearing.*

Step 13

- We highly recommend you **scroll ahead** and **look at the whole procedure** of zip tying the x assembly.
- The procedure is quite simple, but it's hard to understand if you look image-by-image.

ⓘ We'll first tighten both front zip ties, and only then both zip ties in the back.

Step 14







Step 15



Note that on the **left** the rod is **outside**, while on the **right** the rod is **inside**.

Step 16







- Push the rods in place and tighten the back zip ties.

Step 17



Step 18 — Looking good!



- The X assembly is inserted.

Step 19




- Turn the JellyBOX from its back into *normal position*.

Step 20




Step 21



Step 22





⚠ Leave the zip tie **loose**.

Step 23 — ▶ Video: Adjust the X Wire Harness Folding (50s)

- ▶ Video: Adjust the X Wire Harness Folding (50s)
- Adjust the mounting point as needed so that the harness is folding nicely and predictably.

Step 24 — Looking Good!



Step 25 — ↳ Wire up the X Assembly



Step 26




X & Z
end stops
T0 & T1
thermistors
micro
USB


X
motor
X & Z
end stops
T0 & T1
thermistors
micro
USB
5V DC
power

Step 27



Step 28



- In short, connect all the wires according to their labels. We'll start on the left.

Step 29


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
T0 thermistor


D9 (-) Filament Fan
D9 (+) Filament Fan

Step 30







⚠ Make sure to match **plus with plus**...

Step 31



⚠ ... and **minus with minus.**

Step 32





Step 33







⚠ Make sure to match plus with plus and minus with minus.

© 2021

Step 34



This 12V line powers up the Z Probe and the Hotend fan.

Step 35


D10 (-)
Heat Block
D9 (+)
Filament Fan
D8
12V-AUX
AUX-1
AUX-2
Y & Z motors


D10 (-)
Heat Block
D9 (+)
Filament Fan
D8
12V AUX+


D9 filament fan
D10 heat block
E0 motor
X
X & Z end stops
USB
bed
12V DC
D10 (-)
Heat Block
D9 (+)
Filament Fan
D8
Y & Z motors

Step 36


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
T0 thermistor


E0 1B
MOTOR

Step 37


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
E0
E1


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
E1
E0 1B MOTOR
D10 (+)


E0 motor
X motor
X & Z end stops
E1
END STOPS
E0 1B MOTOR
Y 1B MOTOR

Step 38


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
T0 thermistor


X1B
MOTOR

Step 39


D9 filament
E0
X
motor
D10 (+)
Heat Block
Y & Z motors
Y end stop


fan
motor
motor
end stops
D10 (+)
Heat Block
X1B
MOTOR


motor
end stops
X & Z
END_STOPS
Y1B
MOTOR

Step 40


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
T0 thermistor


X STOP
X & Z
T0 & T1

Step 41







Step 42


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
T0 thermistor


Z STOP

Step 43


X & Z
end stops
T0 & T1
thermistors
5V DC
power


X & Z
end stops
T0 & T1
thermistors
Z STOP
LCD & SD
5V DC


X & Z
end stops
T0 & T1
thermistors
Z STOP
LCD & SD
5V DC

Step 44


D9 filament fan
D10 heat block
E0 motor
X motor
X & Z end stops
T0 thermistor
T0

Step 45


X
X & Z
T0 & T1
thermistors
E0
E1
T0 T1 T2
5V DC
POWER


motor
E1
Z STOP
Y
MOTOR


E0
motor
X
motor
X & Z
end stops
E1

Step 46 — It's wired up!





You have installed the X assembly. This is arguably the longest and most complicated part of the whole build, so, kudos!